Bobtot

Portable Party Speaker
Quick Start Guide
ET200

What's in the Box

Check to make sure you have everything below.

ET200 Portable Party Speaker

Wireless Microphone

USB Type-C Charging Cable

3.5mm AUX Audio Cable

Strap

Quick Start Guide

Device Overview

01--------Volume Down
02--------Light mode
03--------Previous Button
04--------Multi-function Button
05--------Play/Pause
06--------Next Button
07--------Power On/Off
08--------Volume Up
09--------AUX Jack/Reset Button
10--------Type-C Charging Port
11--------USB Input

Charging Your Device

Low battery

Charging

Fully charged

USB Type-C charging port (DC 5V)

Turn On/Off

Long Press 2"

ON   OFF

Long Press the POWER button 2 Seconds to turn on/off the Bobtot ET200 portable speaker.

BT Connection/Disconnection

BT Connection

01 Long Press>2"

1. After full charged, long press the POWER button to enter BT pairing mode.
2. Search for the device name "Bobtot ET200" and tap to connect.

02

BT device
On

◁ BT device
On

Avaliable Device
Bobtot ET200

Pairing

Connected

BT Disconnection

Long Press>2"

Long press " ▶|| " to disconnect the current device, and then enter BT pairing new device.

NOTE:
1. Automatically shut down after 10 minutes of no connection in BT mode.

2. Automatically shut down after 20 minutes of no playback or pause after connection.

Wireless Microphone

Power on/off : long press

ECHO: short press , when hear the promt sound of " ECHO Volume " , then short press " + " or " - " to adjust the ECHO volume.
when hear the promt sound of " Microphone Volume " , then short press "+" or " - " to adjust the microphone volume.

Volume + : short press to increase the microphone volume.

Volume - : short press to decrease the microphone volume.

Magic sound: short press : Monster / Baby /Female /Male Voice.

Indicator light

Bobtot

USB Type-C charging port (DC 5V)

Multi-function Mode

M

AUX / USB / BT
Plug AUX or USB flash drive into the speaker, it will automatically play. When using one of the connection ways, please make sure the other source is disconnected.

Short Press

x1

● BT

USB● ↻ ●AUX

Specification

BT Version:	5.3
Output Power:	20W
Operating Range:	33ft (10m)
Battery Capacity:	7.4V 4000mAh
Microphone Battery Capacity:	3.7V 250mAh
Playtime:	Up to 10 hours (Vol 50%)
Charging time:	3.5 hours
Power Supply:	DC 5V
Frequency Response:	90Hz-17KHz
Audio Inputs:	BT/AUX/USB/MIC
IPX Rating:	IPX5

Reset Your Device

If the speaker does not work properly, you may reset it by inserting needle to AUX jack to press and hold the button for approximately 2 seconds until the speaker powers off, and then powers on again.

FCC Statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

FCC Statement

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Need help?

Customer Care Guide
At our company, we strive to provide exceptional customer care to every one of our clients. We believe that building strong relationships with our customers is essential to the success of our business. To help us achieve this goal, we have put together the following customer care guide.

Time
We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.

Feedback
We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.

Solutions
If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs.

Need help?

Here at Bobtot, we take customer care very seriously. Our customers are our first priority, and we are committed to providing the highest quality service.
If you have any questions or concerns, please don't hesitate to reach out to us.
We will be happy to assist you:
Call or Message: +1 888 572 1718
Email: support@bobtot.net

bobtot.net

Bobtot